SI-2000 Adapter Quick install

Direct connected
ethernet cable

TO AP

1 Connect AP Device,
To "TO AP" port,via a ethernet line.

Or

Connect Antenna to the antenna port.

2

Direct connected
ethernet cable

AP CONF

**3** Connect Computer,
To "AP CONF" port,via a ethernet line.

Cross connected
Serial cable

RS-232

4 Connect RS232 Port to Computer.
Maybe a USB-RS232 Translater Device shall be used.

12345678
ON
|CH| CONF

5 Confirm the Switch key is like
this.

DC
48V

+48V PE GND
POWER

6 Connect Switch Power supply
(DC48V) to power port.

13 9 5 1   48V
                12V
                3.3V
   RUN
16 12 8 4

48V,12V,3.3V LED is lighting, Run LED is flashing.

7 Power on.The LED lamp should
light.

Step 1:Remove the 4 top screws,then reomve the top colver.

Then you can see the Wireless Telecom Communicate board, and the SIM card slot.

Step 2: Insert SIM card to slot.

Stp3 Install the 4 top screws of Box, Finish.

8   Insert SIM card, if wireless telcom communication is used.