

SI-1000 Adapter Quick install




Direct connected ethernet line



1 Connect AP Device, To "TO AP" port, via a ethernet line.



Direct connected ethernet line




2 Connect Computer, To "LAN" port, via a ethernet line.




Cross connected Serial line




3 Connect RS232 Port to Computer. Maybe a USB-RS232 Translater Device shall be used.



4 Confirm the Switch key is like this.



5 Connect Switch Power supply (DC48V) to power port.



48V, 12V, 3.3V LED is lighting, Run LED is flashing.

6 Power on. The LED lamp should light.